



MachXO2280 Breakout Board Evaluation Kit

User Guide

Introduction

Thank you for choosing the Lattice Semiconductor MachXO™2280 Breakout Board Evaluation Kit!

This user guide describes how to start using the MachXO2280 Breakout Board, an easy-to-use platform for evaluating and designing with the MachXO2280 PLD. Along with the board and accessories, this kit includes a pre-loaded demonstration design. You may also reprogram the on-board MachXO2280 device to review your own custom designs.

Note: Static electricity can severely shorten the lifespan of electronic components. See the [Storage and Handling](#) section of this document for handling and storage tips.


Features

The MachXO2280 Breakout Board Evaluation Kit includes:

- **MachXO2280 Breakout Board** – The board is a 3" x 3" form factor that features the following on-board components and circuits:
 - MachXO2280 PLD (LCMXO2280C-3FTN256C)
 - USB mini-B connector for power and programming
 - Eight LEDs
 - 40-hole prototype area
 - Eight 2x20 expansion header landings for general I/O, JTAG, and external power
 - 1x8 expansion header landing for JTAG
 - 3.3V supply rail
- **Pre-loaded Demo** – The kit includes a pre-loaded counter design that highlights use of the embedded MachXO2280 oscillator and programmable I/Os configured for LED drive.
- **USB Connector Cable** – The board is powered from the USB mini-B socket when connected to a host PC. The USB channel also provides a programming interface to the LCMXO2280C JTAG port.
- **Lattice Breakout Board Evaluation Kits Web Page** – Visit www.latticesemi.com/breakoutboards for the latest documentation (including this guide), demo designs, and drivers for the kit.

The content of this user guide includes demo operation, programming instructions, top-level functional descriptions of the Breakout Board, descriptions of the on-board connectors, and a complete set of schematics.

Figure 1. MachXO2280 Breakout Board, Top Side



Storage and Handling

Static electricity can shorten the lifespan of electronic components. Please observe these tips to prevent damage that could occur from electro-static discharge:

- Use anti-static precautions such as operating on an anti-static mat and wearing an anti-static wrist-band.
- Store the evaluation board in the packaging provided.
- Touch a metal USB housing to equalize voltage potential between you and the board.

Software Requirements

You should install the following software before you begin developing new designs for the Breakout board:

- FTDI Chip USB Hardware Drivers
- Lattice Diamond™ (MachXO support)
- ispVM System™ 17.9 or later (Required for re-programming)

MachXO2280 Device

This board features the MachXO2280 PLD which offers the benefits of increased system integration by providing over 27Kbits of embedded memory, two built-in PLLs, high performance LVDS I/Os, and a low power sleep mode, all in a single-device. The 256-pin ftBGA package provides 211 user I/Os in a 17mm x 17mm package. A complete description of this device can be found in DS1002, [MachXO Family Data Sheet](#).

Demonstration Design


Lattice provides a pre-programmed demo to illustrate basic operation of the MachXO2280 device. The design integrates an up-counter with the on-chip oscillator.

Note: You may obtain your Breakout Board after it has been reprogrammed. To restore the factory default demo and program it with other Lattice-supplied examples see the [Download Demo Designs](#) section of this document.

Run the Demonstration Design

The preprogrammed demonstration design is an up-counter to drive an LED array. The program shows a clock generator based on the MachXO2280 on-chip oscillator. The counter module is clocked at ~22 MHz (18-26MHz) to illustrate how low speed timer functions can be implemented with a PLD. The 23-bit up-counter further divides the clock to advance the LED display approximately every 200ms. The resulting light pattern will appear as an alternating pair of lit LEDs per row.

Figure 2. Counter Demo Block Diagram



WARNING: Do not connect the Breakout Board to your PC before you follow the driver installation procedure of this section.

Communication with the Breakout Board with a PC via the USB connection cable will require the FTDI chip USB hardware drivers contained in the [Software Requirements](#) section. Loading these drivers enables the computer to reliably recognize and program the Breakout Board. Drivers are distributed by Lattice as a stand-alone package or with ispVM System version 17.9 or later. Use one of the two procedures below to install.

To load the FTDI chip USB hardware drivers via ispVM System:

1. Browse to www.latticesemi.com/breakoutboards and download ispVM System software.
 2. Install ispVM System software.
 3. Run ispVM System. Choose **ispTools > Install/Uninstall LSC USB/Parallel Port Driver**. The LSC 32/64-Bit USB Drivers Install/Uninstall dialog appears.
 4. Select **FTDI USB 32-Bit Driver** or **FTDI USB 64-Bit Driver** then click **Install**. After a few moments, ispVM will indicate the installation is complete.
 5. Click **OK**, then click **Close** from the LSC 32/64-Bit USB Drivers Install/Uninstall dialog.
 6. Choose **File > Exit** to close ispVM System.
 7. Connect the USB cable from a USB port on your PC to the board's USB mini-B socket (J2). After connection is made, a green Power LED (D9) will light indicating the board is powered on.
 8. Red LEDs will light and start to flash according to the preprogrammed demonstration design.
- See the [Troubleshooting](#) section of this guide if the board does not function as expected.

To load the FTDI chip USB hardware drivers via the stand-alone package:

1. Browse to www.latticesemi.com/breakoutboards and download the FTDI chip USB Hardware driver package.
 2. Extract the FTDI chip USB Hardware driver package to your PC hard drive.
 3. Connect the USB cable from a USB port on your PC to the board's USB mini-B socket (J2). After connection is made, a green Power LED (D9) will light indicating the board is powered on.
 4. If you are prompted, "Windows may connect to Windows Update" select **No, not this time** from available options and click **Next** to proceed with the installation. Choose the **Install from specific location (Advanced)** option and click **Next**.
 5. Search for the best driver in these locations and click the **Browse** button to browse to the Windows driver folder created in the Download Windows USB Hardware Drivers section. Select the **CDM 2.04.06 WHQL Certified** folder and click **OK**.
 6. Click **Next**. A screen will display as Windows copies the required driver files. Windows will display a message indicating that the installation was successful.
 7. Click **Finish** to install the USB driver.
 8. Red LEDs will light and start to flash according to the preprogrammed demonstration design.
- See the [Troubleshooting](#) section of this guide if the board does not function as expected.

Download Demo Designs

The counter demo is preprogrammed into the Breakout Board, however over time it is likely your board will be modified. Lattice distributes source and programming files for demonstration designs compatible with the Breakout Board.

To download demo designs:

1. Browse to the Lattice Breakout Board Evaluation Kits web page (www.latticesemi.com/breakoutboards) of the Lattice web site. Select **MachXO Breakout Board Demo Source** and save the file.
2. Extract the contents of **MachXO2280_BB_Eval_Kit_v01.0.zip** to an accessible location on your hard drive. The demo design directory **Demo_LED** is unpacked.

Recompile a Demonstration Project with Lattice Diamond

Use the procedure described below to recompile a demo project for the Breakout Board.

1. Install and license Lattice Diamond software.
2. Download the demo source files from the Lattice Breakout Board Evaluation Kits web page.
3. Run Lattice Diamond.
4. Open the **Demo_LED_OSC.Idf** project file.
5. From the **Process** view, select **JEDEC File** from the **Export Files** process.
6. Choose **Export Files**, right-click and choose **Run**.
After a few moments the JEDEC programming file is output.
7. See section the [Programming with ispVM](#) section for details on downloading a programming file to the board.

Programming with ispVM

A demonstration design is pre-programmed into the Breakout Board by Lattice. To restore a Breakout Board to factory settings or load an alternative demo design, use the procedures in this section.

To install ispVM programming tools:

1. Install and license ispVM System software.
2. Connect the board to a host PC using the USB port header connection.
3. Follow the USB Cable Interface procedure below to program the evaluation board.

The Breakout Board is equipped with a built-in USB-based programming circuit. This consists of a USB PHY and a USB connector. When the board is connected to a PC with a USB cable, it is recognized by the ispVM System software as a USB Download Cable. The MachXO2280 can then be scanned and programmed using the ispVM System software.

To program a demo programming file:

1. From the **Start** menu run ispVM System.
ispVM appears.
2. Choose **Options > Cable and IO Port Setup...**
The Cable and I/O Port Setup dialog appears.
3. Make the following selections:
Cable Type: **USB2**
Port Setting: **FTUSB-0**
Click **OK**.
4. Choose **ispTools > Scan Chain**.
The New Scan Configuration Setup window appears. The **LCMXO2280C** device appears in the device list.
5. Right-click the **LCMXO2280C** entry and choose **Edit Device...**
The Device Information dialog appears.
6. From the Data File section, click the **Browse** button.
The Open Data File dialog appears.
7. Browse to the **<Demo Dir>** folder, select **<Demo>.jed**, and click **Open**. From the Operation list choose **Erase, Program, Verify** and click **OK**.
8. Choose **Project > Download**.
ispVM reprograms the evaluation board.

Programming requires about 10 seconds. A small timer window will appear to show elapsed programming time. At the end of programming, the configuration setup window should show a PASS in the Status column.

MachXO2280 Breakout Board

This section describes the features of the MachXO2280 Breakout Board in detail.

Overview

The Breakout Board is a complete development platform for the MachXO2280 PLD. The board includes a prototyping area, a USB program/power port, an LED array, and header landings with electrical connections to most of the PLD's programmable I/O, power, and JTAG pins. The board is powered by the PC's USB port or optionally with external power. You may create or modify the program files using Diamond software and reprogram the board using ispVM software.

Figure 3. MachXO2280 Breakout Board Block Diagram




Table 1 describes the components on the board and the interfaces it supports.

Table 1. Breakout Board Components and Interfaces

| Component/Interface | Type | Schematic Reference | Description |
|----------------------------|---------|---|--|
| Circuits | | | |
| USB Controller | Circuit | U2: FT2232H | USB-to-JTAG interface and dual USB UART/FIFO IC |
| USB Mini-B Socket | I/O | J1:USB_MINI_B | Programming and debug interface |
| Components | | | |
| LCMXO2280C | PLD | U4: LCMXO2280C-3FTN256C | 2280-LUT device packaged in a 17 x 17mm, 256-ball ftBGA. |
| Interfaces | | | |
| LED Array | Output | D8-D1 | Red LEDs |
| Eight 2x20 Header Landings | I/O | J3: header_2x20 J4: header_2x20 J5: header_2x20 J6: header_2x20 J7: header_2x20 J8: header_2x20 J9: header_2x20 J10: header_2x20 | User-definable I/O |
| 1x8 Header Landing | I/O | J1: header_1x8 | Optional JTAG interface |
| 4-Hole Prototype Area | | | Prototype area 100mil centered holes. |

Subsystems

This section describes the principle sub systems for the Breakout Board in alphabetical order.

Clock Sources

All clocks for the counter demonstration designs originate from the MachXO2280 PLD on-chip oscillator. You may use an expansion header landing to drive a PLD input with an external clock source.

Expansion Header Landings

The expansion header landings provide access to user GPIOs, primary inputs, clocks, and VCCO pins of the MachXO2280. The remaining pins serve as power supplies for external connections. Each landing is configured as one 2x20 100 mil.

Table 2. Expansion Connector Reference

| Item | Description |
|-----------------------|---------------------------------|
| Reference Designators | J3, J4, J5, J6, J7, J8, J9, J10 |
| Part Number | header_2x20 |

Table 3. Expansion Header Pin Information (J3)

| Pin Number | Function | MachXO2280 Ball |
|------------|------------|-----------------|
| 1 | PL2A_LV_T | E4 |
| 2 | PL11A_LV_T | H2 |
| 3 | PL2B_LV_T | E5 |
| 4 | PL11B_LV_C | J2 |
| 5 | GND | n/a |
| 6 | GND | n/a |
| 7 | PL3A_LV_T | F5 |
| 8 | PL12A_LV_T | J1 |
| 9 | PL3B_LV_C | F6 |
| 10 | PL12B_LV_C | K1 |
| 11 | GND | n/a |
| 12 | GND | n/a |
| 13 | PL4A_LV_T | E3 |
| 14 | PL13A_LV_T | L1 |
| 15 | PL4B_LV_C | E2 |
| 16 | PL13B_LV_C | M1 |
| 17 | GND | n/a |
| 18 | GND | n/a |
| 19 | PL5A_LV_T | B1 |
| 20 | PL15A_LV_T | L3 |
| 21 | PL5B_LV_C | C1 |
| 22 | PL15B_LV_C | M3 |
| 23 | GND | n/a |
| 24 | GND | n/a |
| 25 | PL7A_LV_T | F2 |
| 26 | PL16A_LV_T | J4 |
| 27 | PL7B_LV_C | G2 |
| 28 | PL16B_LV_C | J5 |

| Pin Number | Function | MachXO2280 Ball |
|------------|------------|-----------------|
| 29 | GND | n/a |
| 30 | GND | n/a |
| 31 | PL8A_LV_T | G4 |
| 32 | PL17A_LV_T | K5 |
| 33 | PL8B_LV_C | G5 |
| 34 | PL17B_LV_C | K4 |
| 35 | GND | n/a |
| 36 | GND | n/a |
| 37 | PL9A_LV_T | H4 |
| 38 | PL18A_LV_T | M5 |
| 39 | PL9B_LV_C | H5 |
| 40 | PL18B_LV_C | M4 |

Table 4. Expansion Header Pin Information (J4)

| Pin Number | Function | MachXO2280 Ball |
|------------|----------|-----------------|
| 1 | PL3C | F3 |
| 2 | GND | n/a |
| 3 | PL3D | F4 |
| 4 | GND | n/a |
| 5 | PL4C | C3 |
| 6 | GND | n/a |
| 7 | PL4D | C2 |
| 8 | GND | n/a |
| 9 | PL6C | D2 |
| 10 | GND | n/a |
| 11 | PL6D | D1 |
| 12 | GND | n/a |
| 13 | PL7C | E1 |
| 14 | GND | n/a |
| 15 | PL7D | F1 |
| 16 | GND | n/a |
| 17 | PL8C | G3 |
| 18 | GND | n/a |
| 19 | PL8D | H3 |
| 20 | GND | n/a |
| 21 | PL10C | G1 |
| 22 | GND | n/a |
| 23 | PL10D | H1 |
| 24 | GND | n/a |
| 25 | NC | NC |
| 26 | PL15C | M2 |
| 27 | NC | NC |
| 28 | PL15D | N2 |
| 29 | PL11C | J3 |
| 30 | PL16C | R1 |
| 31 | PL11D | K3 |
| 32 | PL16D | R2 |
| 33 | PL12C | K2 |
| 34 | PL17C | L5 |
| 35 | PL12D | L2 |
| 36 | PL17D | L4 |
| 37 | PL14C | N1 |
| 38 | PL19A | N4 |
| 39 | PL14D | P1 |
| 40 | PL19B | N3 |

Table 5. Expansion Header Pin Information (J5)

| Pin Number | Function | MachXO2280 Ball |
|------------|----------|-----------------|
| 1 | PT2C | B2 |
| 2 | PT9A | D8 |
| 3 | PT2D | B3 |
| 4 | PT9C | E8 |
| 5 | PT3A | A2 |
| 6 | PT9D | E9 |
| 7 | PT3B | A3 |
| 8 | PT10A | A10 |
| 9 | PT3C | D3 |
| 10 | PT10C | C9 |
| 11 | PT3D | D4 |
| 12 | PT10D | C10 |
| 13 | PT4A | C4 |
| 14 | PT10E | D9 |
| 15 | PT4B | C5 |
| 16 | PT10F | D10 |
| 17 | PT5A | D6 |
| 18 | PT11A | B9 |
| 19 | PT5B | D5 |
| 20 | PT11B | B10 |
| 21 | PT5C | B4 |
| 22 | PT12A | A11 |
| 23 | PT5D | B5 |
| 24 | PT12B | A12 |
| 25 | PT6E | E7 |
| 26 | PT12C | B11 |
| 27 | PT6F | E6 |
| 28 | PT12D | B12 |
| 29 | PT6C | A5 |
| 30 | PT13C | C11 |
| 31 | PT6D | A4 |
| 32 | PT13D | C12 |
| 33 | PT6A | C6 |
| 34 | PT14A | A13 |
| 35 | PT6B | C7 |
| 36 | PT14B | A14 |
| 37 | PT7A | B6 |
| 38 | PT14C | D11 |
| 39 | PT7B | B7 |
| 40 | PT14D | D12 |

Table 6. Expansion Header Pin Information (J6)

| Pin Number | Function | MachXO2280 Ball |
|------------|------------|-----------------|
| 1 | VCIO_extB7 | G6 |
| 2 | GND | n/a |
| 3 | VCIO_extB6 | J6 |
| 4 | GND | n/a |
| 5 | VCIO_extB5 | L7 |
| 6 | GND | n/a |
| 7 | VCIO_extB4 | L9 |
| 8 | GND | n/a |
| 9 | VCIO_extB3 | J11 |
| 10 | GND | n/a |
| 11 | VCIO_extB2 | G11 |
| 12 | GND | n/a |
| 13 | VCIO_extB1 | F9 |
| 14 | GND | n/a |
| 15 | VCIO_extB0 | F7 |
| 16 | GND | n/a |
| 17 | NC | NC |
| 18 | NC | NC |
| 19 | NC | NC |
| 20 | NC | NC |
| 21 | NC | NC |
| 22 | PT15A | E10 |
| 23 | NC | NC |
| 24 | PT15B | E11 |
| 25 | NC | NC |
| 26 | PT15C | B13 |
| 27 | NC | NC |
| 28 | PT15D | C13 |
| 29 | PT7C | A6 |
| 30 | PT16A | B14 |
| 31 | PT7D | A7 |
| 32 | PT16B | C14 |
| 33 | PT8C | B8 |
| 34 | PT16C | A15 |
| 35 | PT8D | C8 |
| 36 | PT16D | B15 |
| 37 | NC | NC |
| 38 | GND | n/a |
| 39 | NC | NC |
| 40 | GND | n/a |

Table 7. Expansion Header Pin Information (J7)

| Pin Number | Function | LCMXO2280C Ball |
|------------|----------|-----------------|
| 1 | PR4C | F13 |
| 2 | GND | n/a |
| 3 | PR4D | F12 |
| 4 | GND | n/a |
| 5 | PR5C | B16 |
| 6 | GND | n/a |
| 7 | PR5D | C16 |
| 8 | GND | n/a |
| 9 | PR6C | D16 |
| 10 | GND | n/a |
| 11 | PR6D | E16 |
| 12 | GND | n/a |
| 13 | PR7C | F16 |
| 14 | GND | n/a |
| 15 | PR7D | G16 |
| 16 | GND | n/a |
| 17 | PR9C | H12 |
| 18 | GND | n/a |
| 19 | PR9D | H13 |
| 20 | GND | n/a |
| 21 | PR10C | G15 |
| 22 | GND | n/a |
| 23 | PR10D | H15 |
| 24 | GND | n/a |
| 25 | NC | NC |
| 26 | PR15C | M16 |
| 27 | NC | NC |
| 28 | PR15D | N16 |
| 29 | PR11C | J12 |
| 30 | PR16C | L12 |
| 31 | PR11D | K12 |
| 32 | PR16D | L13 |
| 33 | PR13C | J14 |
| 34 | PR17C | M12 |
| 35 | PR13D | K14 |
| 36 | PR17D | M13 |
| 37 | PR14C | K16 |
| 38 | PR20A | L11 |
| 39 | PR14D | L16 |
| 40 | PR20B | M11 |

Table 8. Expansion Header Pin Information (J8)

| Pin Number | Function | MachXO2280 Ball |
|------------|------------|-----------------|
| 1 | PR3A_LV_T | D14 |
| 2 | PR11A_LV_T | H16 |
| 3 | PR3B_LV_C | D13 |
| 4 | PR11B_LV_C | J16 |
| 5 | GND | n/a |
| 6 | GND | n/a |
| 7 | PR4A_LV_T | E13 |
| 8 | PR13A_LV_T | J15 |
| 9 | PR4B_LV_C | E12 |
| 10 | PR13B_LV_C | K15 |
| 11 | GND | n/a |
| 12 | GND | n/a |
| 13 | PR5A_LV_T | E14 |
| 14 | PR14A_LV_T | J13 |
| 15 | PR5B_LV_C | F14 |
| 16 | PR14B_LV_C | K13 |
| 17 | GND | n/a |
| 18 | GND | n/a |
| 19 | PR6A_LV_T | C15 |
| 20 | PR15A_LV_T | L15 |
| 21 | PR6B_LV_C | D15 |
| 22 | PR15B_LV_C | M15 |
| 23 | GND | n/a |
| 24 | GND | n/a |
| 25 | PR7A_LV_T | E14 |
| 26 | PR16A_LV_T | L14 |
| 27 | PR7B_LV_C | F15 |
| 28 | PR16B_LV_C | M14 |
| 29 | GND | n/a |
| 30 | GND | n/a |
| 31 | PR9A_LV_T | G12 |
| 32 | PR17A_LV_T | N15 |
| 33 | PR9B_LV_C | G13 |
| 34 | PR17B_LV_C | N14 |
| 35 | GND | n/a |
| 36 | GND | n/a |
| 37 | PR10A_LV_T | G14 |
| 38 | PR18A_LV_T | N13 |
| 39 | PR10B_LV_C | H14 |
| 40 | PR18B_LV_C | N12 |

Table 9. Expansion Header Pin Information (J9)

| Pin Number | Function | MachXO2280 Ball |
|------------|--------------|-----------------|
| 1 | VCC_3.3V | n/a |
| 2 | GND | n/a |
| 3 | VCC_3.3V | n/a |
| 4 | GND | n/a |
| 5 | VCC_3.3V | n/a |
| 6 | GND | n/a |
| 7 | NC | NC |
| 8 | GND | n/a |
| 9 | NC | NC |
| 10 | VCC_CORE | n/a |
| 11 | CLK0 (PT9B) | D7 |
| 12 | GND | n/a |
| 13 | CLK1 (PT10B) | A9 |
| 14 | GND | n/a |
| 15 | CLK2 (PB10F) | N9 |
| 16 | GND | n/a |
| 17 | CLK3 (PB10B) | M9 |
| 18 | GND | n/a |
| 19 | NC | NC |
| 20 | NC | NC |
| 21 | NC | NC |
| 22 | NC | NC |
| 23 | SLEEPN | P13 |
| 24 | GND | n/a |
| 25 | PB14D | R14 |
| 26 | GND | n/a |
| 27 | PB15A | T14 |
| 28 | GND | n/a |
| 29 | PB15B | T15 |
| 30 | GND | n/a |
| 31 | PB15D | P14 |
| 32 | GND | n/a |
| 33 | PB16A | R15 |
| 34 | GND | n/a |
| 35 | PB16B | R16 |
| 36 | GND | n/a |
| 37 | PB16C | P15 |
| 38 | GND | n/a |
| 39 | PB16D | P16 |
| 40 | GND | n/a |

Table 10. Expansion Header Pin Information (J10)

| Pin Number | Function | MachXO2280 Ball |
|------------|----------|-----------------|
| 1 | PB9B | P8 |
| 2 | PB2A | P2 |
| 3 | PB9A | P7 |
| 4 | PB2B | P3 |
| 5 | PB10E | N8 |
| 6 | PB2C | N5 |
| 7 | PB10C | P9 |
| 8 | PB2D | N6 |
| 9 | PB10D | P10 |
| 10 | PB3A | T2 |
| 11 | PB10A | M10 |
| 12 | PB3B | T3 |
| 13 | PB11C | R9 |
| 14 | PB3C | R4 |
| 15 | PB11D | R10 |
| 16 | PB3D | R5 |
| 17 | PB12A | T10 |
| 18 | PB4A | P5 |
| 19 | PB12B | T11 |
| 20 | PB4B | P6 |
| 21 | PB12C | N10 |
| 22 | PB4C | T5 |
| 23 | PB12D | N11 |
| 24 | PB4D | T4 |
| 25 | PB13A | R11 |
| 26 | PB5A | R6 |
| 27 | PB13B | R12 |
| 28 | PB5B | T6 |
| 29 | PB13C | P11 |
| 30 | PB6A | T8 |
| 31 | PB13D | P12 |
| 32 | PB6B | T7 |
| 33 | PB14A | T13 |
| 34 | PB7C | M7 |
| 35 | PB14B | T12 |
| 36 | PB7D | M8 |
| 37 | PB14C | R13 |
| 38 | PB8C | R7 |
| 39 | NC | NC |
| 40 | PB8D | R8 |

Figure 4. J3/J4 Header Landing Callout




Figure 5. J5/J6 Header Landing Callout




Figure 6. J7/J8 Header Landing Callout




Figure 7. J9/J10 Header Landing Callout





Figure 8. J1 Header Landing and LED Array Callout



MachXO2280 PLD

The LCMXO2280C-3FTN256C is a 256-ball BGA package PLD device which provides 211 I/Os in a 17 x 17mm package.

Table 11. MachXO PLD Interface Reference

| Item | Description |
|-----------------------|--|
| Reference Designators | U4 |
| Part Number | LCMXO2280C-3FTN256C |
| Manufacturer | Lattice Semiconductor |
| Web Site | www.latticesemi.com |

JTAG Interface Circuits

For power and programming an FTDI USB UART/FIFO IC converter provides a communication interface between a PC host and the JTAG programming chain of the Breakout Board. The USB 5V supply is also used as a source for the 3.3V supply rail. A USB mini-B socket is provided for the USB connector cable.

Table 12. JTAG Interface Reference

| Item | Description |
|-----------------------|--|
| Reference Designators | U2 |
| Part Number | FT2232HL |
| Manufacturer | Future Technology Devices International (FTDI) |
| Web Site | www.ftdichip.com |

Table 13. JTAG Programming Pin Information

| Description | MachXO2280 Pin |
|------------------|----------------|
| Test Data Output | 107:TDO |
| Test Data Input | 2:TDI |
| Test Mode Select | 74:TMS |
| Test Clock | 35:TCK |

LEDs

A green LED (D9) is used to indicate USB 5V power. Eight red LEDs are driven by I/O pins of the MachXO2280 device.

Table 14. Power and User LEDs Reference

| Item | Description |
|-----------------------|--|
| Reference Designators | D1, D2, D3, D4, D5, D6, D7, D8, D9 |
| Part Number | LTST-C190KRKT (D1-D8) LTST-C190KGKT (D9) |
| Manufacturer | Lite-On It Corporation |
| Web Site | www.liteonit.com |

Power Supply

3.3V supply rail is converted from the USB 5V interface when the board is connected to a host PC.

Test Points

In order to check the various voltage levels used, test points are provided:

- TP1, VCC3D (VCCIO Bank 0)
- TP2, VCC3D (VCCIO Bank 1)
- TP3, VCC3D (VCCIO Bank 4)
- TP4, VCC3D (VCCIO Bank 5)
- TP5, VCC3D (VCCIO Bank 2)
- TP6, VCC3D (VCCIO Bank 3)
- TP7, VCC3D (VCCIO Bank 7)
- TP8, VCC3D (VCCIO Bank 6)
- TP9, VCC3D (VCC Core)
- TP10, VCC3D (VCCAUX)

USB Programming and Debug Interface

The USB mini-B socket of the Breakout Board serves as the programming and debug interface.

JTAG Programming: For JTAG programming, a preprogrammed USB PHY peripheral controller is provided on the Breakout Board to serve as the programming interface to the MachXO2280 PLD.

Programming requires the ispVM System software.

Table 15. USB Interface Reference

| Item | Description |
|-----------------------|--|
| Reference Designators | U2 |
| Part Number | FT2232HL |
| Manufacturer | Future Technology Devices International (FTDI) |
| Web Site | www.ftdichip.com |

Board Modifications

This section describes modifications to the board to change or add functionality.

Bypassing the USB Programming Interface

The USB programming interface circuit ([USB Programming and Debug Interface](#) section) may be optionally bypassed by removing the 0 ohm resistors: R3, R4, R7, and R9 (See [Appendix A. Schematics](#), Sheet 2 of 5). Header landing J1 provides JTAG signal access for jumper wires or a 1x8 pin header.

Applying External Power

The Breakout Board is powered by the circuit of Schematic Sheet 2 of 4 based on the 5V USB power source. You may disconnect this power source by removing the 0 ohm resistors: R47 (VCCIO 3.3V, Bank 0), R48 (VCCIO 3.3V, Bank 1), R53 (VCCIO 3.3V, Bank 4), R54 (VCCIO 3.3V, Bank 5), R55 (VCCIO 3.3V, Bank 2), R56 (VCCIO 3.3V, Bank 3), R57 (VCCIO 3.3V, Bank 6), R58 (VCCIO 3.3V, Bank 7), R160 (VCC core) and R162 (VCCAUX). Power connections are available from the expansion header landing, J9, Schematic Sheet 3 of 5.

Measuring Bank and Core Voltages

Test points (TP1, through TP10) provide access to power supplies of the MachXO2280 PLD. 0 ohm resistors: R47 (VCCIO 3.3V, Bank 0), R48 (VCCIO 3.3V, Bank 1), R53 (VCCIO 3.3V, Bank 4), R54 (VCCIO 3.3V, Bank 5), R55 (VCCIO 3.3V, Bank 2), R56 (VCCIO 3.3V, Bank 3), R57 (VCCIO 3.3V, Bank 6), R58 (VCCIO 3.3V, Bank 7), R160 (VCC core) and R162 (VCCAUX) can be removed to add a current meter inline or add a resistor shunt to measure voltage across.

Mechanical Specifications

Dimensions: 3 in. [L] x 3 in. [W] x 1/2 in. [H]

Environmental Requirements

The evaluation board must be stored between -40° C and 100° C. The recommended operating temperature is between 0° C and 90° C.

The board can be damaged without proper anti-static handling.

Glossary

PLD: Programmable Logic Device

DIP: Dual in-line package

LED: Light Emitting Diode.

LUT: Look Up Table

PCB: Printed Circuit Board

RoHS: Restriction of Hazardous Substances Directive

USB: Universal Serial Bus

WDT: Watchdog Timer

Troubleshooting

Use the tips in this section to diagnose problems with the Breakout Board.

LEDs Do Not Flash

If power is applied but the board does not flash according to the preprogrammed counter demonstration then it is likely the board has been reprogrammed with a new design. Follow the directions in the [Demonstration Design](#) section to restore the factory default.

USB Cable Not Detected

If ispVM System does not recognize the USB cable even after installing the Lattice USB port drivers and rebooting, the incorrect USB driver may have been installed. This usually occurs if you attach the board to your PC prior to installing the USB driver or ispVM System software.

To access the Troubleshooting the USB Driver Installation Guide:

1. Start ispVM System and choose **Options > Cable and I/O Port Setup**.
The Cable and I/O Port Setup Dialog appears.
2. Click the **Troubleshooting the USB Driver Installation Guide** link.
The Troubleshooting the USB Driver Installation Guide document appears in your system's PDF file reader.
3. Follow the directions of the guide to install the Lattice USB driver.

Determine the Source of a Pre-Programmed Device

You may receive your Breakout Board after it has been reprogrammed by someone else. To restore the board to the factory default, see the [Download Demo Designs](#) section for details on downloading and reprogramming the device.

You can also determine which demo design is currently programmed onto the Breakout Board by comparing the JEDEC checksums against of the programming file with what is read from the programmed device.

To compare JEDEC file checksum:

1. Connect the Breakout Board to a host PC using the USB port.
2. Start ispVM and choose **ispTools > Scan**.
The device appears in the Device List.
3. Double-click the device row.
The Device Information dialog appears.

4. Click the **Browse** button.
The Save as Data File dialog appears.
5. Specify a new JEDEC Data File name and click the **Save** button.
6. From the **Operation** list choose **Read and Save JEDEC** and click **OK**.
7. Choose **Project > Download**.
ispVM reads the contents from the device and writes the results to the JEDEC file specified.

Open the JEDEC file into a text editor and page to the bottom of the file.


Note the hexadecimal checksum at the line above the User Electronic Data note line. Compare this value against the checksum of the original JEDEC demo programming files.

Lattice Diamond Programmer Error

Lattice Diamond 1.1 reports “File not valid error” from the Programmer interface.

Diamond 1.1 is not Programmer compatible with the MachXO2280 Breakout Board. To program the device, use ispVM System 17.9 or later.

Ordering Information

| Description | Ordering Part Number | China RoHS Environment-Friendly Use Period (EFUP) |
|--|----------------------|--|
| MachXO2280 Breakout Board Evaluation Kit | LCMXO2280C-B-EVN |  |

Technical Support Assistance

e-mail: techsupport@latticesemi.com

Internet: www.latticesemi.com

Revision History

| Date | Version | Change Summary |
|---------------|---------|---|
| February 2015 | 1.1 | Updated Subsystems section. Revised the following figures: — Figure 4, J3/J4 Header Landing Callout — Figure 5, J5/J6 Header Landing Callout — Figure 6, J7/J8 Header Landing Callout — Figure 7, J9/J10 Header Landing Callout |
| | | Updated Technical Support Assistance information. |
| | | Updated corporate logo. |
| March 2011 | 01.0 | Initial release. |

© 2015 Lattice Semiconductor Corp. All Lattice trademarks, registered trademarks, patents, and disclaimers are as listed at www.latticesemi.com/legal. All other brand or product names are trademarks or registered trademarks of their respective holders. The specifications and information herein are subject to change without notice.

Appendix A. Schematics

Figure 9. MachXO2280 Breakout Board






Figure 10. USB Interface to JTAG



| | | | |
|---------|--------------------------------------|----------|--------|
| AXELSYS | | | |
| Rev | MachXO Breakout Board, USBIF to JTAG | | |
| Doc | LCMXO2280C-B-EVN | | |
| Part | Version | Location | Sheet |
| | | | 2 of 8 |
| | | | 4 |

Figure 12. MachXO2280



Appendix B. Bill of Materials
Table 16. MachXO2280 Breakout Board Bill of Materials

| Item | Quantity | Reference | Part Number |
|------|----------|---|------------------|
| 1 | 2 | C3, C12 | ECJ-1VB0J475K |
| 2 | 38 | C4, C5, C6, C7, C8, C9, C13, C14, C15, C17, C20, C21, C23, C24, C25, C26, C27, C28, C29, C32, C33, C34, C35, C36, C37, C38, C39, C44, C45, C46, C47, C48, C49, C50, C51, C52, C53, C56 | C0402C104K4RACTU |
| 3 | 2 | C10, C16 | ECJ-1VB0J106M |
| 4 | 1 | C11 | LMK212BJ226MG-T |
| 5 | 2 | C18, C19 | C0402C180K3GACTU |
| 6 | 8 | D1, D2, D3, D4, D5, D6, D7, D8 | LTST-C190KRKT |
| 7 | 1 | D9 | LTST-C190KGKT |
| 8 | 1 | J1 | DNI |
| 9 | 1 | J2 | 5075BMR-05-SM-CR |
| 10 | 8 | J3, J4, J5, J6, J7, J8, J9, J10 | DNI |
| 11 | 1 | J11 | DNI |
| 12 | 3 | L1, L3, L4 | BLM18AG601SN1D |
| 13 | 1 | R1 | RC0402FR-071KL |
| 14 | 18 | R2, R3, R4, R7, R9, R17, R18, R19, R47, R48, R53, R54, R55, R56, R57, R58, R160, R162 | RC0603JR-070RL |
| 15 | 5 | R11, R14, R15, R16, R20 | RC0402FR-075K1L |
| 16 | 1 | R12 | RC0402FR-0712KL |
| 17 | 2 | R21, R161 | RC0402FR-0710KL |
| 18 | 1 | R22 | RC0402FR-072K2L |
| 19 | 8 | R39, R40, R41, R42, R43, R44, R45, R46 | RC0402FR-07470RL |
| 20 | 4 | R49, R50, R51, R52 | RC0402FR-0710RL |
| 21 | 101 | R59, R60, R61, R62, R63, R64, R65, R66, R67, R68, R69, R70, R71, R72, R73, R74, R75, R76, R77, R78, R79, R80, R81, R82, R83, R84, R85, R86, R87, R88, R89, R90, R91, R92, R93, R94, R95, R96, R97, R98, R99, R100, R101, R102, R103, R104, R105, R106, R107, R108, R109, R110, R111, R112, R113, R114, R115, R116, R117, R118, R119, R120, R121, R122, R123, R124, R125, R126, R127, R128, R129, R130, R131, R132, R133, R134, R135, R136, R137, R138, R139, R140, R141, R142, R143, R144, R145, R146, R147, R148, R149, R150, R151, R152, R153, R154, R155, R156, R157, R158, R159 | RC0402FR-07100RL |
| 22 | 10 | TP1, TP2, TP3, TP4, TP5, TP6, TP7, TP8, TP9, TP10 | DNI |
| 23 | 1 | U1 | NCP1117ST33T3G |
| 24 | 1 | U2 | FT2232HL |
| 25 | 1 | U3 | 93LC56T-I/SN |
| 26 | 1 | U6 | DNI |
| 27 | 1 | X1 | 7M-12.000MAAJ-T |